

MMI with radio and standard sound system

from January 2011

**Audi**


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

erWin



J533	Data bus on board diagnostic interface
R	Radio
SF1	Fuse 1 (on fuse panel F)
ST3	Fuse panel 3
T2dn	Double connector
T10i	10-pin connector
T32b	32-pin connector

- | | |
|------|--|
| 50 | Ground connection in luggage compartment, left |
| B444 | OBD connection 1 (in main wiring harness) |
| * | Refer to applicable wiring diagram for fuse positions |
| *2 | Fiber optic cable |
| *3 | Refer to applicable wiring diagram for data bus networking |



Radio, Antenna amplifier 2

- J393 Comfort system central control module
- R Radio
- R11 Antenna
- R24 Antenna amplifier
- R47 Central locking and anti-theft alarm system antenna
- R93 Radio antenna 2
- R111 Antenna amplifier 2
- R112 Antenna amplifier 3
- R170 Satellite antenna
- R183 Digital radio antenna
- R216 Roof antenna
- T2ch Double connector
- T2co Double connector
- T2dl Double connector
- T2dm Double connector
- T4aq 4-pin connector
- T4ba 4-pin connector

50 Ground connection in luggage compartment, left


653 Ground connection on left D-pillar

* USA only

*2 Only for vehicles without TV reception

Radio, Left front treble speaker, Left front bass speaker, Center speaker

- R Radio
- R20 Left front treble speaker
- R21 Left front bass speaker
- R22 Right front treble speaker
- R23 Right front bass speaker
- R208 Center speaker
- T2gs Double connector
- T2gu Double connector
- T2gw Double connector
- T2gx Double connector
- T2gy Double connector
- T8r 8-pin connector
- T10i 10-pin connector
- T17i 17-pin connector, in the left A-pillar connector station
- T23a 23-pin connector, on the left A-pillar
- T23b 23-pin connector, on the right A-pillar
- T27a 27-pin connector, on the left A-pillar
- T27b 27-pin connector, on the right A-pillar
- B101 Left front speaker positive connection (in main wiring harness)
- B102 Left front speaker negative connection (in main wiring harness)
- B103 Right front speaker positive connection (in main wiring harness)
- B104 Right front speaker negative connection (in main wiring harness)
- * from June 2011




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorized by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

ws = white
 sw = black
 ro = red
 rt = red
 br = brown
 gn = green
 bl = blue
 gr = grey
 li = lilac
 vi = lilac
 ge = yellow
 or = orange
 rs = pink

Radio, Left rear treble speaker, Left rear mid-bass speaker, Subwoofer

- R Radio
- R14 Left rear treble speaker
- R16 Right rear treble speaker
- R159 Left rear mid-bass speaker
- R160 Right rear mid-bass speaker
- R211 Subwoofer
- T2go Double connector
- T2gv Double connector
- T2gz Double connector
- T2ha Double connector
- T2hb Double connector
- T8r 8-pin connector
- T10i 10-pin connector
- T27c 27-pin connector, on the left B-pillar
- T27d 27-pin connector, on the right B-pillar



- R71 Speaker positive connection (in left rear door wiring harness)
- R72 Speaker negative connection (in left rear door wiring harness)
- R73 Speaker positive connection (in right rear door wiring harness)
- R74 Speaker negative connection (in right rear door wiring harness)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.